



Fiera 200

47.24" x 41.34" x 74.8"



User Manual



REV1.0 08/25

Important Attention:

Please read these instructions fully before starting assembly.

- 1.. Make sure you have received all the parts. If any parts are missing, please let us know the letter of the parts you need.**
- 2.. Check for packaging and parts for any damage, please take clear photos and contact your sales person.**

Please read the following directions carefully.

Electrical Requirements

Each sauna will require a exclusive circuit when plugged in an outlet. A exclusive circuit requires that no other appliance to share the outlet/circuit with the sauna. Failure to comply with this requirement may cause electrical interruption and diminished performance.

Please make sure the sauna is properly grounded. Serious injury may result if proper electrical requirements are not met.

It is recommended that a qualified electrician install your dedicated electrical wiring for proper sauna functionality and to avoid any potential electrical hazards.

Your sauna plugs directly into a 120V, 15 Amp dedicated outlet.



Package Information

This sauna are packed in 3 cartons, please make sure that you open the boxes face up.

Please be very careful when opening boxes, due to fragile parts and glass. The sauna installation requires at least 2 people.

Where to Start

Lay the cartons flat on the ground and open them carefully.

Open all the cartons, start to install your sauna.
















Tips: Before the start of installation, or at least before installation of the top panel, please remove the dust-proof cover from the top panel to take out the accessories and screws etc.



Cautions to Installation

- 1- No plumbing or plumbing fixtures should be placed in the sauna.
- 2- Keep all liquids away from the heating panels
- 3- Install the sauna on a completely level surface.
- 4- Install the sauna in an area that is dry and protected from the weather.
- 5- Flammable objects and corrosive chemical substances should be kept far away from the sauna.

Fiera IR200 214-129240 List (BOX 1 OF 3)

x1 	x1 	x1 
Top Panel	Bottom Panel	Dust Cover
x1 	x1 	x1 
Bench supporter	Bench	Door Handle
x2 	x1 	x1 
Cup Holder	Towel Rack	Bookshelf
x6 	x10  M3.5*35mm Screw for Bookshelf, Towel rack, fix between top panel and side panel	x4  M3.5*25mm Screw for Cup holder
Wood chip For reinforced glass door and side glasses		x8  M3.5*16mm Screw for dust cover
x1 	x1 	
Wrench for fix screws of door hinges	Help keep wood chips into the gap of glasses	

List (BOX 2 OF 3)

x1 	x1 	x1 
Back Panel	Left Side Panel	Right Side Panel

List (BOX 3 OF 3)

x1 	x1 	x1 
Glass door with door hinges, glass seal strip	Right Side Glass	Right Side Glass

Installation Procedure

Step 1, Place Bottom panel flat on your desired place.



Place the Floor Panel on a level surface.
To avoid damaging your floor, do not move the sauna after assembly; prior to assembly, select a location within reach of a power outlet and pay attention to the orientation of the door to make sure nothing will block it.

Step 2, Place Back panel properly on the rear edge of floor panel.




Please note that the bottom joint should be aligned

Step 3, Install Left Side panel with rear wall, fasten by buckles.



Need one person to hold the Back Panel in place while you position the Left Panel, and fasten by buckles.



Step 4, Install Bench supporter .



Insert the Front Bench Section into the notch in the Left and Right Panels to hold it in place.

Step 5, Install Bench panel, connect all the heater wires to the sockets on back panel, and place Seat panel well.




Connect bench and bottom heater plugs into back panel




Step 6, Install Right Side Panel. Fasten all of buckles.



Need one person to hold the Back Panel in place while you position the Right Side Panel, and fasten by buckles.



Step 7, Install Top panel, draw the wires on top of rear panel and side panels via the holes to the ceiling, and connect all of wires one by one.



Wires of heaters




Wires of control panel



Step 8, Install Side glasses and glass door, need two persons. One person install glass, another one lift the Top panel. Make sure glass embedded into wooden groove between Top panel and Bottom panel. After install side glasses, install glass door and fasten door hinges by screws.




Step 9, After install glass door please install door handle again. Install glass seal strips.



Better fixed glass doors (suitable for front panel all-glass models)

When the glass door appears a little loose and causes it to close untidily,in general,fixing the upper right corner can solve the problem. But according to the actual situation, the customer can reinforce the four angles of the glass door by himself. The reinforcement method is as follows:

Stick double-sided tape on the small piece of wood, or put a drop of glue in the gap, place the small piece of wood in the gap, then hammer it in (with the help of a long piece of wood).



Step 10, After assure all the functions work well, fix Top panel with side panels with screws (3.5M x 16mm)*6 . Install Dust-proof cover with screws (3.5M x 16mm)*8. Don't forget to draw the power cord out of the proper hole.



Finished Sauna

Accessories

These accessories are placed inside the Top panel.

Step 11, Install Cup holder in any corner with screws (M3.5x25mm)*2.

Do Not install it on or in front of heaters. If you don't like or there is no anywhere suitable to install, just ignore it.



Step 12, Install Towel rack on left or right panel with screws (M3.5x35mm)*2.

Do Not install it on or in front of heaters. If you don't like or there is no anywhere suitable to install, just ignore it.



Step 13, Install Book shelf on left or right panel with screws (M3.5x35mm)*2.

Do Not install it on or in front of heaters. If you don't like or there is no anywhere suitable to install, just ignore it.



Operation Instructions of Control Panel



Power Button (On/Off)

This button turns the sauna on or off.



MP3 Switch Button

Insert USB device into the USB port, then press this button to switch to MP3 mode.



FM Switch Button

Press this button to switch to FM (Radio) mode.



Music Control (Play/Pause)

Press this button to play or pause when it is in MP3 mode.



Time Button (Increase/Decrease)

Press the (+) or (-) button to increase or decrease the sauna timer. It will count down until 00 and shut down the heaters.

Tips:

- 1, If you would like to keep the sauna working continuously (no time limit), press and hold both (+) and (-) buttons, the display should show two dashes (--). To start the timer again, just click on one of the Time Control buttons.
- 2, Press the (+) or (-) button to increase or reduce volume.




Temperature Control (Increase/Decrease)

Press the (+) or (-) button to increase or decrease the sauna temperature. The heaters will turn off when the sauna reaches its desired temperature.

Tips:

- 1, Temperature setting ranges from 18 to 65°C (64.4-149 F degrees).
- 2, Press and hold both (+) and (-) buttons to switch the temperature display between Fahrenheit and Celsius.



3, Press the (+) or (-) button to choose next or previous song in MP3 mode, or tune in FM (Radio) mode.



Press this button to connect bluetooth with the devices which have blue-tooth function to play music. If without this button, there is no such a function.



Press this button to change colors of chromo therapy light automatically, if there is any therapy light and operate by the control panel.



Press this button to select color of the chromo therapy light one by one, if there is any therapy light and operate by the control panel.



Press this button to power the interior light (reading light) on or off.



Press this button to power the exterior Light (eave light) on or off, if there is any exterior light. Sometimes it is used to control the LED strip if there is.

Self-Checking and alarm modes

The control panel has self-check function, but it only works when there is something abnormal. Self-checking and alarm modes include:

- a, If the electric relay is abnormal, it alarms 2 long beep every 2 seconds.
- b, If the temperature sensor wire loosen, it alarms 1 long beep every 2 seconds.
- c, If the temperature of driver board is higher than 80°C, it alarms 2 short beep every 2 seconds.
- d, If the signal between driver board and control panel is abnormal, it alarms 3 short beep every 2 seconds.
- e, If the input voltage is too low, it alarms 4 short beep every 2 seconds.
- f, If the wire connection for left loudspeaker loosen, it alarms 1 shot beep and 1 long beep every 2 seconds.
- g, If the wire connection for right loudspeaker loosen, it alarms 1 long beep and 1 shot beep every 2 seconds.

Usage Guide

Conditions to use the sauna:

- 1, Temperature range: +5~+40 °C (41-104 F degrees).
- 2, Relative humidity: ≤85%
- 3, Depression: 700-1060 hPa
- 4, Main supply: AC 110V~120V, Frequency 60Hz ±1

Allow your sauna to warm up for 15-20 minutes or until it reaches 43°C (110 F degrees). You may close the vent on the ceiling to speed up the preheating process.

Drink plenty of water to avoid dehydration during or after the sauna using. It is better not to exceed 40 minutes one time.

When you use the sauna, please switch on the oxygen ionizer. If you still feel stuffy, open the vent in the ceiling to allow fresh air into the sauna.

Tips:

- Start using the sauna within 10 °C before it reaches the set temperature in order to receive the most benefits of the infrared heaters. For example, if you set the sauna to 52°C (125 F degrees) , you'd better start using the sauna when it reaches 46°C (115 F degrees) or 2-3 °C less. Customers reported an average use temperature of 52 °C (125 F degrees) .

Precautions to Use the Sauna

- If the temperature becomes unbearable, decrease the temperature or shut off the sauna immediately.

- Do not use if pregnant or have serious inflammation, a fever, a communicable disease, acute bleeding, or intoxicated.
- Concern the temperature if using the sauna with the elderly or children. Children need adult to accompany when using the sauna.
- Do not consume alcohol or drugs when using the sauna.
- If using prescription drugs, please seek advice of a personal physician or a pharmacist.
- Individuals with cardiovascular conditions or problems (hypertension / hypo tension), congestive heart failure, impaired coronary circulation, which might affect blood pressure, should exercise extreme caution when exposed to prolonged heat.
- Chronic diseases such as Parkinson's, Multiple Sclerosis, Central Nervous System Tumors and Diabetes with Neuropathy are conditions that are associated with impaired sweating.
- The use of Infrared saunas should be avoided by anyone who is predisposed to bleeding.
- An individual that has insensitivity to heat should not use any type of sauna.
- Heating of the low back area of women during the menstrual period may temporarily increase their menstrual flow.
- If have a recent acute joint injury, it should not be heated for the first 48 hours after an injury or until the hot and swollen symptoms subside.
- Metal pins, rods, artificial joints or any other surgical implants should consult a surgeon prior to using an Infrared Sauna.
- Do not splash water on the heaters or any electrical component inside the sauna.
- Do not bring wet towels into your sauna or any substances that could harm the interior of your sauna.
- Do not install a lock on your sauna.
- All repairs need to be authorized by the supplier's representative; otherwise product warranty may be voided.

***In the rare event, you feel painful and/or
discomfortable, immediately discontinue sauna use.***

Cleaning and Maintenance

Use a clean damp towel to wipe off the bench, floor and around the back panel.

Do not use a towel that is too wet and can drip water inside the sauna and do not use cleaning agents inside the sauna.

Make sure to keep the sauna dry and clean. Do not leave towels or water glasses or bottles inside the sauna after use.

Wipe the exterior surface of the sauna with a towel and clean the glass at least once a month.

Wood Care

If the sauna exterior body was scratched or scuffed, it can be concealed by using a small amount of furniture polish, oil or other furniture treatment.

The interior blemishes, scratches, or scuffs can be either left alone, sanded or combination of gluing plus sanding.

Please avoid any treatment containing benzene or a high concentration of alcohol.

Troubleshooting

The sauna does not power on

- Make sure the main power plug of the sauna is connected to the socket at your home.
- Make sure the main power plug is connected to the electric box on the top of sauna.
- Make sure the overload protector did not turn off.
- Make sure the control panel wire is connected well.
- Make sure the power socket at your home is working by trying a different device on the same socket.

Control panel displays abnormal or has malfunction

- To make sure whether the wires for control panel connected well. There are 3 connections of the wires: to the control panel, to the

circuit board, middle connection on roof.

- Replace a new wire for control panel.
- Replace a new control panel.

LED Reading Light

- Make sure the wires connect well.
- Replace the light bulb.

One or a few heaters do not work

- Make sure the heaters' plugs connected well on top of the sauna.
- Make sure the heaters' plugs under the bench are connected well.
- Floor heater and bench heater are not as hot as other heaters (by design).
- Make sure the plug behind the heater is connected (you would need to unscrew the heater).

***For more troubleshooting advice or to report a problem,
please contact with your supplier.***